


Issue: 2  
Date: 010607



ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	SA153.01	MOTOR HOUSING	20	SA153.20	FRONT END PLATE
2	SA153.02	VALVE BUSHING	21	SA153.21	BEARING
3	SA153.03	O-RING	22	SA153.22	SPINDLE GEAR
4	SA153.04	THROTTLE VALVE	23	SA153.23	MOTOR CLAMP
5	SA153.05	O-RING	24	SA153.24	ANGLE HEAD HOUSING
6	SA153.06	VALVE SPRING	25	SA153.25	OIL PLUG
7	SA153.07	O-RING	26	SA153.26	BEARING
8	SA153.08	VALVE SCREW	27	SA153.27	PINION GEAR
9	SA153.09	THROTTLE LEVER	28	SA153.28	BEARING
10	SA153.10	THROTTLE LEVER PIN	29	SA153.29	LOCK NUT
11	SA153.11	EXHAUST SLEEVE	30	SA153.30	SPINDLE
12	SA153.12	INLET BUSHING	31	SA153.31	KEY
13	SA153.13	BEARING	32	SA153.32	WHEEL COVER
14	SA153.14	REAR END PLATE	33	SA153.33	WHEEL COVER SCREW
15	SA153.15	DOWEL PIN	34	SA153.34	WHEEL SCREW NUT
16	SA153.16	CYLINDER	35	PTC/50G	GRINDING DISC
17	SA153.17	ROTOR	36	SA153.36	11mm SPANNER WRENCH
18	SA153.18	ROTOR BLADE	37	SA153.37	DOWEL PIN
19	SA153.19	ROTOR COLLAR	38	SA153.38	GRINDING DISC WRENCH