



Item	Part No.	Description
1	CP20VCV.01	Decorative Cover (R/S Dust Cup)
2	CP20VCV.02	Decorative Cover (R/S Housing)
3	CP20VCV.03	Dust Cap Button
4	CP20VCV.04	Dust Cap Button Spring
5	CP20VCV.05	Switch Button
6	CP20VCV.06	Switch
7	CP20VCV.07	Connection Wire (A)
8	CP20VCV.08	Casing Screw
9	CP20VCV.09	Right Side Housing (With Soft Grip)
10	CP20VCV.10	Dust Cap
11	CP20VCV.11	Rubber Spacer
12	CP20VCV.12	Fixing Screw for Rubber Spacer
13	CP20VCV.13	Air Filter Bracket
14	CP20VVCVCF	Cloth Filter Cartridge

Item	Part No.	Description
15	CP20VCV.15	Motor Cover
16	CP20VCV.16	Motor
17	CP20VCV.17	Sponge Filter
18	CP20VCV.18	Battery Base (Right Side)
19	CP20VCV.19	Fixing Screw for Battery Base
20	CP20VCV.20	Connection Wire (B)
21	CP20VCV.21	Connectioin Wire (C)
22	CP20VCV.22	Battery Connector
23	CP20VCV.23	Decorative Cover (L/S Dust Cup)
24	CP20VCV.24	Left Side Housing (with Soft Grip)
25	CP20VCV.25	Battery Base (L/S)
26	CP20VCV.26	Decorative Cover (L/S Housing)
27	CP20VCV.27	Filter Sponge (Round)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.