


Item	Part No.	Description
1	TC024010004	Wheel - HBS97
1	TCNR0010011	Wheel - HBS971
2	TC029010023	Base
3	TC020010042	Case, Column
4	TC020010091	Plate, Regulator Wheel
5	TC025010002	Column
6	TC025010004	Spring, Vertical Slide
7	TC024010002	Optical Box
8	TC025030011	Black Handle
9	TC025030014	Lens, 200mm
10	TC025030013	Lens Stand
11	TC027010037A	Aiming screen (HBS97.V2)
11	TC027010056	Aiming screen (HBS971)
14	TC025020009	Spring
15	TC020010038	Spirit-Level
16	TC026010011	Spring
17	TC020020031	Luxmeter 0/240
18	TC020010152	Steel Cover
20	TC020020018	PCB with Photodiode
22	TC020010050	Plexiglass Cover
23	TC025010005	Vertical Sliding System
24	TC025010135	Spring Pusher
26	TCNA0010009	Screw, M4 x 20
27	TC025010130	Brake, VSS
30	TC025020011	Mirror Visor
35	TCNA2010002	Screw, M8 x 50 - HBS97
35	TCNA2010016	Screw, M8 x 55 - HBS971
36	TCNA5010010	Screw, M6 x 16
37	TCNA0010010	Screw, M5 x 45
38	TC020010047	Wheel Axle, 15 x 45mm
39	TC022040010	Pedal Brake
40	TC024010041	Pivot-Thread, Brake
42	TCNA0010009	Screw, M6 x 16
44	TCNB0010002	Nut, M10
45	TCNA0010002	Screw, M10 x 16
46	TC029010049	Plate, Regulator
47	TCNA6010005	Screw, M8 x 35
58	TCNC0010005	Washer
60	TCNA4010025	Screw, M4 x 13
61	TCNB0010004	Nut, M3
64	TC025010068	Washer
65	TCND1010002	Bearing, 6005RS
66	TC022040014	Ferrule, Brake
68	TC025010122	Plate, Mirror Visor
69	TC025010121	Compass, Mirror Visor
70	TC025010123	Washer, PVC
72	TC025010119	Washer
73	TCNA1010034	Screw, M10 x 80
74	TCNA0010025	Screw, M8 x 16
76	TCNA0010009	Screw, M6 x 16
77	TCNA1010034	Screw, M4 x 16
81	TC020010037	Spring, Spirit Level
82	TCNB0010005	Nut, M8
83	TCNA4010006	Screw, 3.9 x 9.5
84	TCNB1010006	Nut, M8
85	TCNA2010013	Screw, M8 x 20
86	TCNA2010011	Screw, M8 x 60
87	TCNB1010011	Nut, M8
88	TC025020059	Kit, Rail, Complete - HBS97



All Items are common to both models except where specified in the item description.

Issue Date: 06/09/05
 Version No: 1