


Issue: 2
Date Issued: 020702



ITEM	PART NO.	DESCRIPTION
1	TC180A/01	Nut
2	TC180A/02	Washer
4	TC180A/04	Spring washer
5	TC180A/05	Blade guard
6	TC180A/06	Riving knife
7	TC180A/07	Bolt
8	TC180A/08	Table
9	TC180A/09	End cap
10	TC180A/10	Bracket
11	TC180A/11	Rip fence
12	TC180A/12	Screw
13	TC180A/13	Bracket
14	TC180A/14	Screw
15	TC180A/15	Washer
16	TC180A/16	Washer
17	TC180A/17	Thumb screw
18	TC180A/18	Fixing screw
19	TC180A/19	Washer
20	TC180A/20	Lower guard
21	TC180A/21	Nut
22	TC180A/22	Outer flange

ITEM	PART NO.	DESCRIPTION
23	TC180A/23	Blade
24	TC180A/24	Inner flange
25	TC180A/25	Lower plate
26	TC180A/26	Bolt
27	TC180A/27	Steel plate
28	TC180A/28	Bracket
29	TC180A/29	Housing
30	TC180A/30	Screw
31	TC180A/31	Nut
32	TC180A/32	Tension knob
33	TC180A/33	Bolt
34	TC180A/34	Motor
35	TC180A/35	Screw
36	TC180A/36	Rear cover
37	TC180A/37	Washer
38	TC180A/38	Nut
39	TC180A/39	Clamp
40	TC180A/40	Bolt
41	TC180A/41	Cable gland
42	TC180A/42	Cable
43	TC180A/41	Switch unit
44	TC180A/42	Water Tray