

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

1.1 GENERAL SAFETY

- WARNING!** Ensure that Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with the applications, limitations, and potential hazards of the tester.
- ✓ Keep the tester clean and in good condition.
- ✓ Protect the tester from the following: Static electricity, High temperatures.
- ✓ **DO NOT** get the tester wet or use in damp or wet locations or areas where there is condensation.
- ✗ **DO NOT** use the tester for any purpose other than for which it is designed.
- ✗ **DO NOT** allow untrained persons (particularly children) to operate the tester.
- ✗ **DO NOT** operate the tester when you are tired or under the influence of alcohol, drugs or

2. INTRODUCTION & SPECIFICATIONS

Detects and confirms radio frequency and/or infra red emission from key fobs and remote controls. Helps diagnose faults quickly and easily without the need to dismantle the fob, remote or vehicle. Magnetic backing sticks to the side of any ferrous surface making distance test of transmitter a possibility. Suitable for a wide variety of vehicle and electronic/electrical applications. Suitable for detecting new BMW frequencies. Powered by 9.0V battery (not included).

Detects: Infra-red or Radio Frequency RF Ranges: 418MHz, 433-434MHz, 868MHz

3. OPERATION INSTRUCTIONS

3.1 ASSEMBLY

- 3.1.1 Slide the battery cover off from the rear of the tester.
- 3.1.2 Insert a 9V/PP3 battery (not included).
- 3.1.3 Make sure polarity is correct
- 3.1.4 Replace battery cover.

3.2 USING THE TESTER

- 3.2.1 Switch the unit on by pressing the "ON/OFF" button, this will illuminate the green L.E.D at the top of the tester.
- 3.2.2 Secure the tester to a metal surface using the magnetic pad on the rear of the tester.
- 3.2.3 Aim a working key fob at the tester and operate the key fob, an L.E.D at the top will flash once.
Now test the suspect key fob.
- 3.2.4 If the suspect key fob does not trigger the L.E.D, change the key fob's battery and repeat the procedure.
- 3.2.5 The tester can also be used to determine the strength/range of a key fob's signal.

Note:

The tester need not be switched off as it has an "auto-shutdown" function (approx. 1 mins. without use). This tester can also pick up test home entertainment remotes and other similar devices.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this equipment. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

