

RECHARGEABLE FLEXIBLE FLOODLIGHT WITH TRIPOD, 24W COB LED & 5W SMD LED, 2000LM, BUILT-IN POWER BANK

MODEL NO: **LED240**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



1. SAFETY

1.1. ELECTRICAL SAFETY

USE ONLY THE SUPPLIED USB CABLE FOR CONNECTING FLOODLIGHT TO THE POWER SUPPLY.

WARNING! It is the user's responsibility to read, understand and comply with the following electrical instructions:

You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products, particularly portable equipment which is plugged into an electrical supply not protected by an RCCB. You must also read and understand the following instructions concerning electrical safety.

1.1.1. **The Electricity At Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT).

The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. If in any doubt about electrical safety, contact a qualified electrician.

Inspect the USB cable and connector for wear and damage to ensure items are safe before connecting to a power supply. If worn or damaged **DO NOT** use.

1.2. BATTERY SAFETY

- □ **WARNING!** To reduce the risk of burns or fire:
- DO NOT attempt to open, disassemble, modify or service the battery.
- **DO NOT** expose to temperatures above 60°C (140°F).
- **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.

1.3. **GENERAL SAFETY**

- ✓ Ensure the floodlight is correctly charged before initial use.
- **DO NOT** cover or block the lens during use.
- DO NOT turn the floodlight on when it is being charged.
- DO NOT shine directly into your, other person's or animal's eyes.
- DO NOT allow children to use the floodlight.
- DO NOT handle or move the floodlight whilst it is being charged.
- **DO NOT** use the floodlight if you suspect that the battery or the spotlight casing is damaged.
- **DO NOT** immerse the floodlight in water.
- ✓ Use tripod on a stable surface.
- ✓ Ensure the floodlight is allowed to cool before attempting any cleaning or storage.
- ✓ When not in use, store the floodlight in a safe, dry, childproof location.

2. INTRODUCTION

Three super bright 8W COB LED panels produce up to 2000 lumens and a smaller 5W SMD LED spotlight produces 400 lumens. Folding LED panels create a 360° spread of light or rotate and tilt to create a focused beam of light. Mounted on a 1.1m tripod for simple positioning of light and hands-free operation. Built-in power bank with 5V=1A USB output for providing power on the go. Features a magnetic base and hook which provide more mounting options. 3.7V 4Ah lithium-ion battery for extended battery life with a long run time of 4hr. Easy to read charge indicator displays the current battery level during use and while charging. Charges via USB-C cable

3. SPECIFICATION

Model No:	LED240
Battery:	3.7V Lithium-ion 4Ah
Charging Time:	6hr
Colour Temperature:	3000K & 6000K
IP Rating:	IPX3
LED Type:	COB LED + SMD LED
Lumen Output:	2000lm
Weight:	1.78kg
Operating Time:	Side(High/Low)/Top: (2/4) 8hr
Power:	24W + 5W
USB Output:	5V=1A

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time. We will provide warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

Note:

The lithium battery does not suffer from memory effect and once fully charged may be stored for up to six months without another charge.

4. OPERATION

■ WARNING! Ensure that you read, and fully understand the safety instructions before use.

4.1. BATTERY CHARGING

NOTE: Before initial use, fully charge the unit. Direct the lens away from your eyes before switching on.

- 4.1.1. Ensure the floodlight is turned off before charging.
- 4.1.2. Battery charge level is indicated by the charge % display.
- 4.1.3. When full charge (100%) has been reached, unplug the charger cable from the power supply.

4.2. SPOTLIGHT (Lefthand button)

First press: On full Second press: On half Third press: Flash Fourth press: Off

4.3. LED PANELS (Righthand button)

First press: On full Second press: On half Third press: On yellow full Fourth press: On yellow half

Fifth press: On full (white) Sixth press: Off

4.4. FIT TRIPOD TO FLOODLIGHT

4.4.1. Screw thread on top of tripod into base of floodlight.

5. MAINTENANCE

- 5.1. Wipe down dirty surfaces with damp cloth. DO NOT use abrasive or caustic cleaning materials.
- 5.2. Dispose of broken unit in accordance with local authority battery regulations.
 - **DO NOT** dispose of with regular refuse.
- 5.3. STORAGE
- 5.3.1. Store the charger in a safe, dry location.



LEGS



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.



Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 og sales@sealey.co.uk oww.sealey.co.uk